

# Module `htpio`

---

***Hardware Test Platform (HTP) Remote I/O Classes and Modules.***

HTPIO is an executable package, which allows the user to test or use some of its library functionality from the command line.

*Set value using telnet:*

```
htpio -p telnet set --host 192.168.199.31 --pin 14 --val 1
```

*Get value using socket:*

```
htpio -p socket get --host 192.168.199.31 --pin 14
```

*Lock/Unlock pin:*

```
htpio -p telnet lock --host 192.168.199.31 --pin 14  
htpio -p socket unlock --host 192.168.199.31 --pin 14
```

## Sub-modules

---

- [htpio.bridge](#)
- [htpio.decorators](#)
- [htpio.exceptions](#)
- [htpio.socketio](#)
- [htpio.telnetio](#)

# Module `htpio.bridge`

---

This module provides the connection between the client application and the remote i/o implementation.

***Example :***

```
import time
import htpio.bridge as bridge
import htpio.telnetio as telnetio
import htpio.socketio as socketio

device = telnetio.RaspberryPi('192.168.199.31')
gpio = bridge.RemoteAccess(device)

gpio.lock(14)
gpio.configure(14, gpio.OUTPUT)

gpio.set(14, 1)
time.sleep(1)
gpio.set(14, 0)

gpio.unlock(14)
gpio.deconfigure(14)
gpio.logout()

device = socketio.RaspberryPi('192.168.199.31')
gpio = bridge.RemoteAccess(device)

gpio.lock(15)
gpio.configure(15, gpio.OUTPUT)

gpio.set(15, 1)
time.sleep(1)
gpio.set(15, 0)

gpio.unlock(15)
gpio.deconfigure(15)
gpio.logout()
```

## Classes

### Class Device

```
class Device(*args, **kwargs)
```

Define the implementor's interface from the bridge pattern. This interface provides homogeneous interface for all remote I/O libraries.

Typically the implementor interface provides only primitive operations, and abstraction defines higher-level operations based on these primitives.

## Descendants

- [htpio.socketio.RaspberryPi](#)
- [htpio.telnetio.RaspberryPi](#)

## Class variables

### Variable INPUT

Pin input mode

### Variable OUTPUT

Pin output mode

## Methods

### Method configure

```
| def configure(self, pin, direction)
```

Abstract method

### Method deconfigure

```
| def deconfigure(self, pin)
```

Abstract method

### Method get

```
| def get(self, pin)
```

Abstract method

### Method isconfigured

```
| def isconfigured(self, pin)
```

Abstract method

### Method islocked

```
| def islocked(self, pin)
```

Abstract method

**Method lock**

```
| def lock(self, pin)
```

Abstract method

**Method login**

```
| def login(self)
```

Abstract method

**Method logout**

```
| def logout(self)
```

Abstract method

**Method reset**

```
| def reset(self, pin)
```

Abstract method

**Method set**

```
| def set(self, pin, value)
```

Abstract method

**Method unlock**

```
| def unlock(self, pin)
```

Abstract method

**Class RemoteAccess**

```
| class RemoteAccess(device_api)
```

Define the abstraction's interface from the bridge pattern used by the client application.

Typically the implementor interface provides only primitive operations, and abstraction defines higher-level operations based on these primitives.

## Methods

### Method `configure`

```
| def configure(self, pin, direction)
```

Configure pin with direction if it is free

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.configure(14, led.OUTPUT)
led.set(14, 1)
...
```

### Method `deconfigure`

```
| def deconfigure(self, pin)
```

Deconfigure pin if it belongs to my session

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.deconfigure(14)
...
```

### Method `get`

```
| def get(self, pin)
```

Get pin value

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.configure(14, led.OUTPUT)
led.set(14, 1)
print(led.get(14))
...
```

#### Method `isconfigured`

```
| def isconfigured(self, pin)
```

Check if pin is configured

*Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.isconfigured(14)
...
```

#### Method `islocked`

```
| def islocked(self, pin)
```

Check if pin is locked by another process

*Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.lock(14)
if led.islocked(14):
    print("LED is locked!!!")
```

```
led.logout()  
...
```

#### Method `lock`

```
| def lock(self, pin)
```

Lock pin if it is not used

#### *Example:*

```
from htpio.bridge import RemoteAccess  
from htpio import telnetio, socketio  
  
remoteio = socketio.RaspberryPi('192.168.199.31')  
led = RemoteAccess(remoteio)  
led.lock(14)  
...
```

#### Method `login`

```
| def login(self)
```

Registers to remote device

#### *Example:*

```
from htpio.bridge import RemoteAccess  
from htpio import telnetio, socketio  
  
remoteio = socketio.RaspberryPi('192.168.199.31')  
led = RemoteAccess(remoteio)  
led.login()  
...
```

#### Method `logout`

```
| def logout(self)
```

Unregisters from remote device

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.logout()
...
```

#### Method `reset`

```
| def reset(self, pin)
```

Remove pin lock forcefully

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.lock(14)
print(led.islocked(14))
led.reset(14)
print(led.islocked(14))
...
```

#### Method `set`

```
| def set(self, pin, value)
```

Write value to pin

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.configure(14, led.OUTPUT)
led.set(14, 1)
```

```
print(led.get(14))
```

```
...
```

#### Method `unlock`

```
| def unlock(self, pin)
```

Unlock pin if it belongs to my session

#### *Example:*

```
from htpio.bridge import RemoteAccess
from htpio import telnetio, socketio

remoteio = socketio.RaspberryPi('192.168.199.31')
led = RemoteAccess(remoteio)
led.unlock(14)
...
```

## Module `htpio.decorators`

This module implement various decorators such as function calls and exception logging.

Decorators are used to implement additional functionality to a method or function without changing its name.

Currently the following decorators are implemented :

- `@countcalls` - Counts the number of function calls
- `@logger(filename)` - Logs function exceptions to a give file

#### *Example:*

```
from htpio.decorators import Countcalls, Logger

@Countcalls
def f():
    pass

count = 0
```

```
for i in range(100):
    count = i + 1
    f()

    print(f.count(), count)
```

```
@Countcalls
@Logger(LOGFILE)
def f():
    return 1 / 0

# Function under test
raised = False
try:
    f()
except:
    raised = True
logger.log.info("Number of calls==[{0}]".format(f.count))
```

## Classes

---

### Class Countcalls

```
| class Countcalls(f)
```

Decorator that keeps track of the number of times a function is called.

<https://wiki.python.org/moin/PythonDecoratorLibrary>

**Example:**

```
from htpio.decorators import Countcalls

@Countcalls
def f():
    pass

@Countcalls
def g():
    pass

count = 0
for i in range(100):
    count = i + 1
    f()
```

```
g()

print(f.count()) # Number of calls for function f
print(g.count()) # Number of calls for function g
print(Countcalls.counts()) # Dump number of calls for f and g
```

## Class variables

### Variable instances

Stores the function names and number of calls

## Static methods

### Method counts

```
| def counts()
```

Return a dictionary for all registered functions as keys and the number of function calls as values.

## Methods

### Method count

```
| def count(self)
```

Return the number of times the function was called.

## Class Logger

```
| class Logger(logfile)
```

Decorator that logs exceptions into a given file.

### *Example:*

```
from htpio.decorators import Logger

@Logger('c:\test.log')
def f():
    return 1 / 0

### Function under test
raised = False
```

```
try:  
    f()  
except:  
    raised = True  
    logger.log.info("Number of calls==[{0}]".format(f.count()))
```

## Class variables

### Variable `log`

Instance of a logging object

### Variable `logfile`

Log file use to store the logs

# Module `htpio.exceptions`

---

This module implements all exception classes used by htpio.

## Classes

---

### Class `CannotConnectToTarget`

```
| class CannotConnectToTarget(*args, **kwargs)
```

Raised the object cannot connect to the specified [target:socket].

#### Ancestors (in MRO)

- [builtins.Exception](#)
- [builtins.BaseException](#)

### Class `CannotCreateLockDirectory`

```
| class CannotCreateLockDirectory(*args, **kwargs)
```

Raised when the lockfolder cannot be created.

#### Ancestors (in MRO)

- [builtins.Exception](#)

- [builtins.BaseException](#)

## Class `CannotMountRamDisk`

```
| class CannotMountRamDisk(*args, **kwargs)
```

Raised when the ram disk cannot be mapped to the lock folder.

### Ancestors (in MRO)

- [builtins.Exception](#)
- [builtins.BaseException](#)

## Class `InvalidLoginDetails`

```
| class InvalidLoginDetails(*args, **kwargs)
```

Raised when user or password provided not valid.

### Ancestors (in MRO)

- [builtins.Exception](#)
- [builtins.BaseException](#)

## Class `PinLockedByOtherProcess`

```
| class PinLockedByOtherProcess(lock_owner=None,  
| my_session=None)
```

Raised when the gpio pin locked by another htpio process.

### Ancestors (in MRO)

- [builtins.Exception](#)
- [builtins.BaseException](#)

## Module `htpio.socketio`

---

This is a socket i/o control module wrapping the python pigpio client.

PIGPIO is a client/server

library using sockets for remote control of the general purpose input outputs (GPIO).

**Example:**

```
import htio.socketio as socketio

r = socketio.RaspberryPi(host = '192.168.199.31',
                         port = 8888)

try:
    r.lock(14)
except:
    r.logout()
    raise

r.configure(14, socketio.RaspberryPi.OUTPUT)
r.set(14, 1)

print(r.get(14))

r.unlock(14)
r.deconfigure(14)
```

## Classes

---

### Class RaspberryPi

```
class RaspberryPi(host=None, port=8888)
```

This class allows users to connect and control the GPIO on a Raspberry remotely by using and extending the pigpio library.

### Configuration

Enable Remote GPIO

```
sudo raspi-config
Menu : Interfacing Options -> Remote GPIO
```

Enable pigpiod to start on boot

```
sudo systemctl enable pigpiod
```

## Class attributes

LOCK_DIR	: Location of lock files (ramdisk)
MAX_GPIO	: Maximum number of gpio locks ( from 0 .. MAX)
INPUT	: GPIO is digital input
OUTPUT	: GPIO is digital output
EOF	: End of file

## Instance attributes

host	: ip v4 address
port	: port (from 0 to 65535)

## Public methods

islocked(gpio)	: Check if the gpio is locked
lock(gpio)	: Locks the gpio
unlock(gpio)	: Unlocks the gpio
isconfigured(gpio)	: Checks if the gpio is configured
configure(gpio, direction)	: Configures the gpio with direction
deconfigure(gpio)	: Restores the default configuration
get(gpio)	: Reads the gpio status
set(gpio, value)	: Writes new value to gpio
login()	: Registers to the remote system
logout()	: Unregisters from the remote system
reset()	: Deletes all configuration data

## Constructor

When called with host address, the constructor creates a telnet connection and performs automatic login (default=8888).

```
import htpio.socketio as socketio

t = socketio.RaspberryPi('192.168.199.31')
```

## Ancestors (in MRO)

- [pigpio.pi](#)
- [htpio.bridge.Device](#)

## Class variables

### Variable `EOF`

Symbol for end of transmission

### Variable `LOCKDIR`

Lock files directory

### Variable `MAX_GPIO`

Maximum number of GPIOs

## Methods

### Method `configure`

```
| def configure(self, pin, direction)
```

Configures the gpio for input or output operation.

#### *Example:*

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')

led.configure(14, socketio.RaspberryPi.OUTPUT)
...
```

### Method `deconfigure`

```
| def deconfigure(self, pin)
```

Removes the gpio configuration.

#### *Example:*

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')
```

```
led.deconfigure(14)  
...
```

#### Method `get`

```
| def get(self, pin)
```

Reads the value of the gpio.

#### *Example:*

```
import htpio.socketio as socketio  
  
led = socketio.RaspberryPi('192.168.199.31')  
  
led.get(14)  
...
```

#### Method `isconfigured`

```
| def isconfigured(self, pin)
```

Check if gpio is configured by comparing the current direction configuration with the default one (INPUT).

#### *Example:*

```
import htpio.socketio as socketio  
  
led = socketio.RaspberryPi('192.168.199.31')  
  
led.configure(14, socketio.RaspberryPi.OUTPUT)  
if led.isconfigured(14):  
    print("LED is configured!!!")  
...
```

#### Method `islocked`

```
| def islocked(self, pin)
```

Opens the gpio lock file and checks it size. If the size is more than zero then the gpio is considered to be locked by another process.

#### *Example:*

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')
led.lock(14)
if led.islocked(14) :
    print("LED is locked!!!")
...

```

#### **Method lock**

```
| def lock(self, pin)
```

Lock the given pin by creating a lock file and writing the current session id into it.

#### ***Example:***

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')
led.lock(14)
...

```

#### **Method login**

```
| def login(self)
```

Registers device for use with target device by checking for an established connection and creating all gpio lock files.

#### ***Example:***

```
import htpio.socketio as socketio

led = socketio.RaspberryPi()
led.host = '192.168.199.31'
led.port = 8888
led.login()
...

```

#### **Method logout**

```
| def logout(self)
```

Unregisters device from remote device.

***Example:***

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')

led.logout()

...
```

**Method `reset`**

```
| def reset(self, pin)
```

Deletes the content of all generated lock files.

***Example:***

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')

led.reset(14)

...
```

**Method `set`**

```
| def set(self, pin, value)
```

Writes the value to the gpio.

***Example:***

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')

led.configure(14, socketio.RaspberryPi.OUTPUT)
led.set(14, 1)
...
```

### Method `unlock`

```
| def unlock(self, pin)
```

Unlock the pin by truncating the size of the lock file to zero.

#### *Example:*

```
import htpio.socketio as socketio

led = socketio.RaspberryPi('192.168.199.31')
led.unlock(14)
...
```

## Module `htpio.telnetio`

This is a telnet client i/o control module.

Telnet is a client/server text-oriented communication protocol using a virtual terminal connection and operates over TCP. It provides a command-line interface to the operating system on a remote host.

#### *Example:*

```
import htpio.telnetio as telnetio

r = telnetio.RaspberryPi(host = '192.168.199.31',
                         port = 23,
                         user = 'pi',
                         password = 'raspberry')

try:
    r.lock(14)
except:
    r.logout()
    raise

r.configure(14, telnetio.RaspberryPi.OUTPUT)
r.set(14, 1)

print(r.get(14))
```

```
r.unlock(14)
r.deconfigure(14)
```

## Classes

### Class RaspberryPi

```
class RaspberryPi(host=None, port=23, user='htp',
password='sokotnar', login_prompt='login:',
password_prompt='Password:', shell_prompt='$', timeout=20)
```

RaspberryPi telnet remote i/o access class.

This class provides basic functionality for controlling the GPIO by using a remote telnet session and sending commands to the operating system.

### Configuration

The user should be part of the sudo and gpio group and the visudo file should be configured for no password prompt when using the sudo. This is accomplished by executing the following commands :

```
sudo adduser htp
sudo usermod -a -G gpio htp
sudo usermod -a -G sudo htp

sudo visudo
(add line) htp      ALL=(ALL) NOPASSWD: ALL
(add line) %gpio    ALL=(ALL) NOPASSWD: ALL
```

### Class attributes

LOCK_DIR	Location of lock files (ramdisk)
MAX_GPIO	Maximum number of gpio locks ( from 0 .. MAX)
INPUT	GPIO is digital input
OUTPUT	GPIO is digital output
EOF	End of file

## Instance attributes

```
host          : ip v4 address
port          : port (from 0 to 65535)
user          : user
password      : user password
login_prompt  : token to detect when login is expected
password_prompt: token to detect when password is expected
shell_prompt  : token to detect return after command execution
timeout       : timeout time in case of connectivity problems
```

## Public methods

```
islocked(gpio)        : Check if the gpio is locked
lock(gpio)            : Locks the gpio
unlock(gpio)          : Unlocks the gpio
isconfigured(gpio)    : Checks if the gpio is configured
configure(gpio, direction) : Configures the gpio with direction
deconfigure(gpio)     : Restores the default configuration
get(gpio)             : Reads the gpio status
set(gpio, value)      : Writes new value to gpio
login()               : Registers to the remote system
logout()              : Unregisters from the remote system
reset()               : Deletes all configuration data
```

## Constructor

When called with host address, the constructor creates a telnet connection and performs automatic login:

```
import htpio.telnetio as telnetio

t = telnetio.RaspberryPi('192.168.199.31')
```

When called without host address, the constructor creates an unconnected instance. In this case the object might be configured by using the instance attributes:

```
import htpio.telnetio as telnetio

t = telnetio.RaspberryPi()
```

```
t.host = '192.168.199.31'  
t.port = 23  
t.user = 'user'  
t.password = 'password'  
t.login_prompt = 'login:'  
t.password_prompt = 'Password:'  
t.shell_prompt = '$'  
t.timeout = 20
```

After the configuration above the user is required to use the following statements:

```
t.open(host, port)  
t.login()
```

## Ancestors (in MRO)

- [telnetlib.Telnet](#)
- [htpio.bridge.Device](#)

## Class variables

### Variable `EOF`

Character used to mark end of line transmission

### Variable `LOCKDIR`

Directory containing the lock files

### Variable `MAX_GPIO`

Maximum number of gpio lock files

### Variable `RAMDISK`

Label for the ramdisk mounted on the lock directory

## Methods

### Method `configure`

```
|     def configure(self, pin, direction)
```

Create the sysfs virtual folder for gpio manipulation.

**Shell :**

```
echo 14 | tee /sys/class/gpio/export
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')

led.configure(14, telnetio.RaspberryPi.OUTPUT)
...
```

**Method deconfigure**

```
| def deconfigure(self, pin)
```

Delete the sysfs virtual folder for pin manipulation.

**Shell :**

```
echo 14 | tee /sys/class/gpio/unexport
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')

led.deconfigure(14)
...
```

**Method get**

```
| def get(self, pin)
```

Gets the current status of the given pin by reading the system file.

**Shell :**

```
cat /sys/class/gpio/gpio14/value
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')

led.get(14)
...
```

**Method `isconfigured`**

```
| def isconfigured(self, pin)
```

This function checks if the sysfs folder /sys/class/gpio/gpioNN exists.

**Shell:**

```
find /sys/class/gpio -name gpio14
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')

led.configure(14, telnetio.RaspberryPi.OUTPUT)
if led.isconfigured(14):
    print("LED is configured!!!")
...
```

**Method `islocked`**

```
| def islocked(self, pin)
```

Check if pin is already locked by an object of this class and returns the identification number of the locking process.

**Shell:**

```
sudo cat /tmp/htp/locks/gpio14
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')
led.lock(14)
if led.islocked(14) :
    print("LED is locked!!!")
...
```

**Method** `lock`

```
| def lock(self, pin)
```

Throws an exception **PinLockedByOtherProcess** or opens the gpio lock file and writes the session id in it.

**Shell:**

```
echo 1921681993055555 | sudo tee /tmp/htp/gpio14
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')
led.lock(14)
...
```

**Method** `login`

```
| def login(self)
```

Performs an automatic login to the remote system using the supplied user and password as instance properties.

!!! Use only when creating an unconnected instance !!!

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi()
```

```
led.host = '192.168.199.31'  
led.port = 23  
led.user = 'htpio'  
led.password = 'sokotnar'  
  
led.open(host, port)  
led.login()  
  
...
```

#### Method `logout`

```
| def logout(self)
```

Closes the connection to the target.

#### *Example:*

```
import htpio.telnetio as telnetio  
  
led = telnetio.RaspberryPi('192.168.199.31')  
  
led.logout()  
  
...
```

#### Method `reset`

```
| def reset(self, pin)
```

Deletes lock file for pin.

#### *Example:*

```
import htpio.telnetio as telnetio  
  
led = telnetio.RaspberryPi('192.168.199.31')  
  
led.reset(14)  
  
...
```

#### Method `set`

```
| def set(self, pin, value)
```

Sets the current value of the given pin by using the system file.

**Shell:**

```
echo 1 | sudo tee /sys/class/gpio/gpio14
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')

led.configure(14, telnetio.RaspberryPi.OUTPUT)
led.set(14, 1)
...
```

**Method `unlock`**

```
| def unlock(self, pin)
```

Unlocks the gpio by deleting the content of the lock file.

**Shell:**

```
sudo truncate --size=0 /tmp/htp/locks/gpio14
```

**Example:**

```
import htpio.telnetio as telnetio

led = telnetio.RaspberryPi('192.168.199.31')
led.unlock(14)
...
```